



 **KERFKORE**
Flex Education Series
Kerfkore®
Attachment Techniques

Kerfkore® Attachment Techniques

Method 1

Rabbet Attachment

- Make a 1-1/2" X 96" strip of 1/4" Kerfkore and cover with a vertical grade laminate
- Use this as a measuring tape
- Can also use 1/2" or 3/4" Kerfkore and cut a 1/4" rabbet joint into one edge of it.

NOTE: Make sure the panel rabbet joints are the same thickness as the rabbet joint in the measuring tape area.

Because Kerfkore is attached after lamination, an allowance must be made for the offset. There must be enough space built in to permit the depth of the rabbet joint to recess into the top and bottom or side pieces.



Method 2

Uncut Attachment



Method 3

Side Cut Attachment



Method 4

Top Butt Attachment

When measuring, use a cloth measuring tape or non-stretching string to wrap around perimeter.

Because Kerfkore is attached after lamination, an allowance must be made for the offset. There must be enough space built in to permit the depth of the Butt joint to recess into the top and bottom or side pieces.



Method 5

Side Butt Attachment

When measuring, use a cloth measuring tape or non-stretching string to wrap around perimeter.

Because Kerfkore is attached after lamination, an allowance must be made for the offset. There must be enough space built in to permit the depth of the Butt joint to recess into the top and bottom or side pieces.

