

OVERVIEW

- Decorative surfaces are applied to Kerfkore and the adjoining areas in the flat position.
- Kerfkore does not have to be the same thickness as the rest of the structure. The difference in the thickness will show up on the inside, not the outside of most structures.

PRO TIP:

Less adhesive is generally better than too much. Use a test strip to determine the correct amount of pressure and adhesive.

Kerfkore Chosen as 2021 Architizer A+Product Awards Finalist.

Read the article:



Let's get started!

1.



Maintain 1/8" spacing between pieces.

2.



Apply adhesive to both the decorative surface and Kerfkore substrate.

3.



Optional:
Use of vinyl blades for positioning of material.

Apply decorative surface to Kerfkore.



Apply pressure with a J-Roller to ensure good adhesion.



Trim edges using a router.



Form to desired radius.

Congratulations! Your project is complete, but this is just the beginning of opportunities with our Kerfkore products.

[LEARN ABOUT KERFKORE](#)

[DO'S & DON'TS](#)

[REQUEST A SAMPLE](#)

[KERFKORE SPEC SHEET](#)