



## Timberflex

### DO

- Attach to framework before applying decorative surfacing material. Should be installed using conventional fabrication methods.
- Attach to framework using glues, staples or nails.
- Always attach to horizontal support ribs. The use of three ribs (top, middle, & bottom) is recommended.
- Use of Vertical Grade HPL as a decorative surfacing material is preferred. A Horizontal Grade HPL can be used, provided it will bend to the desired radius.
- Any type of face veneer can be used as the decorative surfacing material. (10 mil paperback, wood on wood two-ply, phenolic-backed veneer, etc.)

### DON'T

- **DO NOT** laminate flat when using HPL, Phenolic-Backed veneer or other stiff materials.
- **DO NOT** attach to vertical ribs except where seaming is to be done. If vertical ribs are used, attaching through these ribs may deflect the panel and distort the shape.
- **DO NOT** attach product directly onto drywall.
- **AVOID** allowing decorative surfacing material to end on a radius. Especially horizontal grade laminates or other similarly rigid materials.

For additional fabrication tips please visit the **Fabrication Steps** or **Technical Guide** sections at [www.kerfkore.com](http://www.kerfkore.com). For application questions and technical assistance, call us at **800-637-3539**.

Components are **CARB II** and **TSCA Title VI** compliant **Third Party Certified**



912 264 6496



kerfkore.com



2630 Sidney Lanier Drive Brunswick, GA 31525