



 **KERFKORE**
Flex Education Series
Timberflex
Framework Fabrication

Timberflex Framework Fabrication

All vertical ribs should be set slightly back from the horizontal ribs so they will not interfere in the forming process.

Only attach to flush vertical rib when forming a seam.

Step 1

Use traditional methods to construct the framework.



Step 2

Use glue, screws and staples for construction.



Step 3

Horizontal ribs should be used to attach Timberflex to the framework.



Step 4

In most applications at least three ribs are recommended.

(Taller fixtures may require additional ribs)



Step 5

Vertical ribs are not needed to attach Timberflex.

Only use to support and position the horizontal ribs.



Next Steps

See Timberflex Attachment Methods