



Worklite[®]

(Formerly Foamkore[®])

IMPORTANT

Worklite Panels must be acclimated to the fabrication area for 2-3 days before processing. Separate by placing uniform spacers between each panel allowing for air circulation to both faces. This will provide for uniform humidity conditions.

Worklite is a balanced constructed product. The Worklite core materials are laminated with a moisture resistant glue to provide a durable lightweight panel.

Follow instructions below to help maintain the stability of Worklite panels.

1. To allow for air circulation, **KEEP WORKLITE IN A DRY AREA** away from direct contact with the floor.
2. **MUST** store on a flat uniform surface.
3. **COVER** Worklite with a sheet to maintain uniform moisture levels. (Sheet may need to be lightly weighted to keep cover tight to the top panel during storage.)
4. **DO NOT** place excessive weight on the panels during storage.
5. If panels are stored on the edge, **MAKE SURE** they are vertical without excessive pressure to either side.
6. In order to maintain balanced panels, similar face treatments **MUST BE** performed on each side of the panels.

For additional fabrication tips please visit the Fabrication Steps or Technical Guide sections at www.kerfkore.com. For application questions and technical assistance, call us at 800-637-3539.

Components are **CARB II** and **TSCA Title VI** compliant Third Party Certified



912 264 6496



kerfkore.com



2630 Sidney Lanier Drive Brunswick, GA 31525