

STORAGE AND HANDLING

- For proper air circulation, **STORE WORKLITE IN A DRY AREA** on a flat uniform surface, away from direct contact with the floor.
- Acclimate panels to the fabrication area 2-3 days before processing.
- To provide for uniform humidity conditions, place uniform spacers between each panel for proper air circulation.
- Use a cover sheet to maintain uniform moisture levels. A small amount of weight (e.g. ¾" MDF board) is required to keep the cover sheet tight during storage.
- **DO NOT** place excessive weight on the panels during storage.
- When storing panels vertically, make sure there is no excessive weight or pressure on either side. Keep as vertical as possible to avoid warping.

DECORATIVE SURFACING APPLICATION

- To maintain balanced panels, similar decorative surfacing treatments **MUST BE** performed on each side of the panels.
- Acceptable decorative surfaces include high-pressure laminates, veneers, metals, leathers, paints, stains, or other similar materials.
- Use of contact adhesive with J-Roller or PVA glue with press machine is preferred when attaching decorative surfaces.
- **DO NOT** use contact adhesive / petroleum-based adhesives on the foam itself.

**For additional fabrication tips, visit kerfkore.com/resources/
For questions and technical assistance, call 800-637-3539.**

Components are **CARB II** and **TSCA Title VI** compliant
Third Party Certified