

## TIMBERFLEX

## FLEXBOARD®

## ECONOKORE®

### ✓ DO

- Attach to framework before applying decorative surfacing material.
- Attach to framework using glues, staples or nails.
- **ALWAYS** attach to framework using horizontal support ribs. Use three ribs (top, middle, & bottom).
- Lamination Application - Use a vertical grade HPL. A horizontal grade HPL can be used, provided it will bend to the desired radius.
- Veneer Application – Use any type of face veneer as the decorative surfacing material.
- Flexboard can be laminated flat, bending down to a 16" radius. Must use single-ply or paperbacked veneer.

### ✗ DON'T

- **DON'T** apply laminate flat before attaching to framework.
- **DON'T** attach to vertical ribs except where seaming is to be done. If vertical ribs are used, attaching through these ribs may deflect the panel and distort the shape.
- **DON'T** attach product directly onto drywall.
- **AVOID** ending decorative surfacing material on a radius. Especially horizontal grade laminates or other similarly rigid materials.

**For additional fabrication tips, visit [kerfkore.com/resources/](https://kerfkore.com/resources/)  
For questions and technical assistance, call 800-637-3539.**

Components are **CARB II** and **TSCA Title VI** compliant  
Third Party Certified