

 **KERFKORE**
Flex Education Series
Kerfkore®
Splicing
(Without Fasteners, Height)

Kerfkore® Splicing Without Fasteners

(Additional Height)

Laminates are applied to Kerfkore and adjoining areas in the flat position prior to attachment to the structure.


Kerfkore does not need to be the same thickness as the rest of the structure. Difference in the thickness will show up on the inside of most structures.

Step 1

Make sure grooves are aligned between pieces.

(Align kerfs using a piece of 1/8" hardboard)

No gluing is required, the laminate will hold the materials together.



Step 2


Apply adhesive to both the laminate and Kerfkore substrate.



Step 3


Apply laminate.

Optional: Use vinyl blades for material positioning



Step 4

Apply pressure to insure good adhesion.



Step 5

Trim edges using a router.



Step 6

Finished Product

