

OVERVIEW

- This guide will focus on building half the column.
- To build the full column, you would repeat this process for both halves of the column and adjoin them.

PRO TIP:

There are many methods for attaching Soflex to framework:

- Rabbet
- Uncut
- Side Cut
- Top Butt
- Side Butt

For a more indepth guide to attachment methods, check out our Flex Ed Series:



Let's get started!

1.




Outfit frame using horizontal ribs.

2.



Apply PVA/White glue adhesive outside face of horizontal ribs.

3.



Optional:
Attachment method includes placing a dado along the center ribs.


Use a pre-sized, pre-laminated flat piece of Soflex. Lay across the ribs using glue. Kerfs should run vertical with the length of the column.




Apply moderate pressure across the entire surface to ensure Soflex attaches to frame.



Use hot melt along ribs to help hold in place until the PVA glue sets.



Use a router to trim excess laminate.



Completed half column.

Congratulations! Your project is complete, but this is just the beginning of opportunities with our Soflex products.

[LEARN ABOUT SOFLEX](#)

[DO'S & DON'TS](#)

[REQUEST A SAMPLE](#)

[SOFLEX SPEC SHEET](#)